

Manual Transaxle Workshop Manual A65M–R

FOREWORD

This manual explains the structure, operation, and service points for the above-indicated manual transaxle. In order to do these procedures safely, quickly, and correctly, you must first read this manual and any other relevant service materials carefully.

The information in this manual is current up to April, 2002. Any changes that occur after that time will not be reflected in this particular manual. Therefore, the contents of this manual may not exactly match the mechanism that you are currently servicing.

**Mazda Motor Corporation
HIROSHIMA, JAPAN**

CONTENTS

Title	Section
General Information	GI
Overhaul	J
Technical Data	TD
Special Tools	ST

© 2002 Mazda Motor Corporation
PRINTED IN THE NETHERLANDS, APRIL 2002
1739–1E–02D

WARNING

Servicing a vehicle can be dangerous. If you have not received service-related training, the risks of injury, property damage, and failure of servicing increase. The recommended servicing procedures for the vehicle in this workshop manual were developed with Mazda-trained technicians in mind. This manual may be useful to non-Mazda trained technicians, but a technician with our service-related training and experience will be at less risk when performing service operations. However, all users of this manual are expected to at least know general safety procedures.

This manual contains "Warnings" and "Cautions" applicable to risks not normally encountered in a general technician's experience. They should be followed to reduce the risk of injury and the risk that improper service or repair may damage the vehicle or render it unsafe. It is also important to understand that the "Warnings" and "Cautions" are not exhaustive. It is impossible to warn of all the hazardous consequences that might result from failure to follow the procedures.

The procedures recommended and described in this manual are effective methods of performing service and repair. Some require tools specifically designed for a specific purpose. Persons using procedures and tools which are not recommended by Mazda Motor Corporation must satisfy themselves thoroughly that neither personal safety nor safety of the vehicle will be jeopardized.

The contents of this manual, including drawings and specifications, are the latest available at the time of printing, and Mazda Motor Corporation reserves the right to change the vehicle designs and alter the contents of this manual without notice and without incurring obligation.

Parts should be replaced with genuine Mazda replacement parts or with parts which match the quality of genuine Mazda replacement parts. Persons using replacement parts of lesser quality than that of genuine Mazda replacement parts must satisfy themselves thoroughly that neither personal safety nor safety of the vehicle will be jeopardized.

Mazda Motor Corporation is not responsible for any problems which may arise from the use of this manual. The cause of such problems includes but is not limited to insufficient service-related training, use of improper tools, use of replacement parts of lesser quality than that of genuine Mazda replacement parts, or not being aware of any revision of this manual.

GENERAL INFORMATION

HOW TO USE THIS MANUAL	GI-2
RANGE OF TOPICS	GI-2
SERVICING PROCEDURE	GI-2
SYMBOLS	GI-3
ADVISORY MESSAGES	GI-4
UNITS	GI-5
UNITS TABLE	GI-5
FUNDAMENTAL PROCEDURES	GI-6
PREPARATION OF TOOLS AND MEASURING	
EQUIPMENT	GI-6
SPECIAL SERVICE TOOLS	GI-6
DISASSEMBLY	GI-6
INSPECTION DURING REMOVAL,	
DISASSEMBLY	GI-6
ARRANGEMENT OF PARTS	GI-7
CLEANING OF PARTS	GI-7
REASSEMBLY	GI-7
ADJUSTMENT	GI-8
RUBBER PARTS AND TUBING	GI-8
HOSE CLAMPS	GI-8
TORQUE FORMULAS	GI-8
WISE	GI-9
ELECTRICAL SYSTEM	GI-9
CONNECTORS	GI-9
NEW STANDARDS	GI-12
NEW STANDARDS TABLE	GI-12
ABBREVIATIONS	GI-14
ABBREVIATIONS TABLE	GI-14

HOW TO USE THIS MANUAL

HOW TO USE THIS MANUAL

RANGE OF TOPICS

AME201000001M01


- This manual contains procedures for performing all required service operations. The procedures are divided into the following five basic operations:
 - Removal/Installation
 - Disassembly/Assembly
 - Replacement
 - Inspection
 - Adjustment
- Simple operations which can be performed easily just by looking at the vehicle (i.e., removal/installation of parts, jacking, vehicle lifting, cleaning of parts and visual inspection) have been omitted.

SERVICING PROCEDURE

AME201000001M02

Inspection, Adjustment

- Inspection and adjustment procedures are divided into steps. Important points regarding the location and contents of the procedures are explained in detail and shown in the illustrations.



XME2010001

Repair Procedure

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. However, only removal/installation procedures that need to be performed methodically have written instructions.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration. In addition, symbols indicating parts requiring the use of special service tools or equivalent are also shown.

HOW TO USE THIS MANUAL

3. Procedure steps are numbered and the part that is the main point of the procedure is shown in the illustration with the corresponding number. Occasionally, there are important points or additional information concerning a procedure. Refer to this information when servicing the related part.

Procedure

"Removal/Installation" Portion

"Inspection After Installation" Portion

INSTALL THE PARTS BY PERFORMING STEPS 1—3 IN REVERSE ORDER

SHOWS THERE ARE REFERRAL NOTES FOR SERVICE

SHOWS SERVICE ITEM (S)

LOWER TRAILING LINK, UPPER TRAILING LINK REMOVAL/INSTALLATION

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the undercover. (See N-5 Undercover Removal)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.
5. Inspect the rear wheel alignment and adjust it if necessary.

INDICATES ANY RELEVANT REFERENCES WHICH NEED TO BE FOLLOWED DURING INSTALLATION

SHOWS PROCEDURE ORDER FOR SERVICE

SHOWS TIGHTENING TORQUE SPECIFICATIONS

SHOWS SPECIAL SERVICE TOOL (SST) FOR SERVICE OPERATION

SHOWS APPLICATION POINTS OF GREASE, ETC.

SHOWS EXPENDABLE PARTS

SHOWS DETAILS

SHOWS TIGHTENING TORQUE UNITS

Non-Expendable Parts

1	Split pin	7	Split pin
2	Nut	8	Nut
3	Lower trailing link ball joint (See P-6 Lower Trailing Link Ball Joint Removal Note)	9	Upper trailing link ball joint (See P-6 Upper Trailing Link Ball Joint Removal Note)
4	Bolt	10	Nut
5	Lower trailing link	11	Upper trailing link
6	Dust boot (lower trailing link)	12	Dust boot (upper trailing link)

Lower Trailing Link Ball Joint, Upper Trailing Link Ball Joint Removal Note

- Remove the ball joint using the SSTs.

SHOWS SPECIAL SERVICE TOOL (SST) NO.

48 T028 304 UPPER TRAILING LINK
48 T028 305 LOWER TRAILING LINK
KVUCKLE
48 T028 303

SHOWS REFERRAL NOTES FOR SERVICE

XME2010010

End Of Step

SYMBOLS

AME201000001M03

- There are eight symbols indicating oil, grease, fluids, sealant, and the use of **SST** or equivalent. These symbols show application points or use of these materials during service.

Symbol	Meaning	Kind
	Apply oil	New appropriate engine oil or gear oil
	Apply brake fluid	New appropriate brake fluid
	Apply automatic transaxle/transmission fluid	New appropriate automatic transaxle/transmission fluid

HOW TO USE THIS MANUAL

Symbol	Meaning	Kind
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly
	Replace part	O-ring, gasket, etc.
	Use SST or equivalent	Appropriate tools

End Of Step

ADVISORY MESSAGES

AME201000001M04

- You will find several **Warnings**, **Cautions**, **Notes**, **Specifications** and **Upper and Lower Limits** in this manual.

Warning

- A Warning indicates a situation in which serious injury or death could result if the warning is ignored.

Caution

- A Caution indicates a situation in which damage to the vehicle or parts could result if the caution is ignored.

Note

- A Note provides added information that will help you to complete a particular procedure.

Specifications

- The values indicate the allowable range when performing inspections or adjustments.

Upper and Lower Limits

- The values indicate the upper and lower limits that must not be exceeded when performing inspections or adjustments.

End Of Step

UNITS

UNITS

UNITS TABLE

AME201200002M01

Electrical current	A (ampere)
Electric power	W (watt)
Electric resistance	ohm
Electric voltage	V (volt)
Length	mm (millimeter)
	in (inch)
Negative pressure	kPa (kilo pascal)
	mmHg (millimeters of mercury)
	inHg (inches of mercury)
Number of revolutions	rpm (revolutions per minute)
Positive pressure	kPa (kilo pascal)
	kgf/cm ² (kilogram force per square centimeter)
	psi (pounds per square inch)
Torque	N·m (Newton meter)
	kgf·m (kilogram force meter)
	kgf·cm (kilogram force centimeter)
	ft·lbf (foot pound force)
	in·lbf (inch pound force)
Volume	L (liter)
	US qt (U.S. quart)
	imp qt (Imperial quart)
	ml (milliliter)
	cc (cubic centimeter)
	cu in (cubic inch)
	fl oz (fluid ounce)
Weight	N (Newton)
	g (gram)
	oz (ounce)

Conversion to SI Units (Système International d'Unités)

- All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

Rounding Off

- Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

Upper and Lower Limits

- When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7 kgf/cm² in the following specifications:

210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}
270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

- The actual converted values for 2.7 kgf/cm² are 265 kPa and 38.4 psi. In the first specification, 2.7 is used as an upper limit, so the converted values are rounded down to 260 and 38. In the second specification, 2.7 is used as a lower limit, so the converted values are rounded up to 270 and 39.

End Of Site


FUNDAMENTAL PROCEDURES

FUNDAMENTAL PROCEDURES

PREPARATION OF TOOLS AND MEASURING EQUIPMENT

AME201400004M01

- Be sure that all necessary tools and measuring equipment are available before starting any work.




WGIWXX0023E

End Of Step

SPECIAL SERVICE TOOLS

- Use special service tools or equivalent when they are required.

AME201400004M02




WGIWXX0024E

End Of Step

DISASSEMBLY

- If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be marked in a place that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.

AME201400004M03




WGIWXX0027E

End Of Step

INSPECTION DURING REMOVAL, DISASSEMBLY

- When removed, each part should be carefully inspected for malfunction, deformation, damage, and other problems.

AME201400004M04



WGIWXX0028E


End Of Step

FUNDAMENTAL PROCEDURES

ARRANGEMENT OF PARTS

- All disassembled parts should be carefully arranged for reassembly.
- Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.

AME201400004M05



WGIWXX0029E

End Of Step


CLEANING OF PARTS

- All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

Warning

- **Using compressed air can cause dirt and other particles to fly out causing injury to the eyes. Wear protective eye wear whenever using compressed air.**

AME201400004M06




WGIWXX0030E

End Of Step


REASSEMBLY

- Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.
- If removed, these parts should be replaced with new ones:
 - Oil seals
 - Gaskets
 - O-rings
 - Lockwashers
 - Cotter pins
 - Nylon nuts
- Depending on location:
 - Sealant and gaskets, or both, should be applied to specified locations. When sealant is applied, parts should be installed before sealant hardens to prevent leakage.
 - Oil should be applied to the moving components of parts.
 - Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.

AME201400004M07



WGIWXX0031E



WGIWXX0032E


End Of Step

FUNDAMENTAL PROCEDURES

ADJUSTMENT

- Use suitable gauges and/or testers when making adjustments.

AME201400004M08




WGIWXX0033E

End Of Site

RUBBER PARTS AND TUBING

- Prevent gasoline or oil from getting on rubber parts or tubing.

AME201400004M09




WGIWXX0034E

End Of Site

HOSE CLAMPS

- When reinstalling, position the hose clamp in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a good fit.

AME201400004M10



WGIWXX0035E


End Of Site

TORQUE FORMULAS

- When using a torque wrench-SST or equivalent combination, the written torque must be recalculated due to the extra length that the SST or equivalent adds to the torque wrench. Recalculate the torque using the following formulas. Choose the formula that applies to you.

Torque Unit	Formula
N·m	$N \cdot m \times [L / (L + A)]$
kgf·m	$kgf \cdot m \times [L / (L + A)]$
kgf·cm	$kgf \cdot cm \times [L / (L + A)]$
ft·lbf	$ft \cdot lbf \times [L / (L + A)]$
in·lbf	$in \cdot lbf \times [L / (L + A)]$

AME201400004M11



WGIWXX0036E


A : The length of the **SST** past the torque wrench drive
L : The length of the torque wrench

FUNDAMENTAL PROCEDURES, ELECTRICAL SYSTEM

WISE

- When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.

AME201400004M12



WGIWXX0037E

End Of S.e

ELECTRICAL SYSTEM

CONNECTORS


AME201700006M01

Data Link Connector

- Insert the probe into the service hole when connecting a jumper wire to the data link connector.

Caution


- Inserting a jumper wire probe into the data link connector terminal may damage the terminal.



X3U000WAY


Disconnecting Connectors

- When disconnecting connector, grasp the connectors, not the wires.



WGIWXX0041E

- Connectors can be disconnected by pressing or pulling the lock lever as shown.




WGIWXX0042E

ELECTRICAL SYSTEM

Locking Connector


- When locking connectors, listen for a click indicating they are securely locked.



X3U000WB1

Inspection

- When a tester is used to inspect for continuity or measuring voltage, insert the tester probe from the wiring harness side.




WGIWXX0044E

- Inspect the terminals of waterproof connectors from the connector side since they cannot be accessed from the wiring harness side.

Caution

- To prevent damage to the terminal, wrap a thin wire around the tester probe before inserting into terminal.




WGIWXX0045E

Terminals

Inspection

- Pull lightly on individual wires to verify that they are secured in the terminal.




WGIWXX0064E

ELECTRICAL SYSTEM


Replacement

- Use the appropriate tools to remove a terminal as shown. When installing a terminal, be sure to insert it until it locks securely.
- Insert a thin piece of metal from the terminal side of the connector and with the terminal locking tab pressed down, pull the terminal out from the connector.



Sensors, Switches, and Relays

- Handle sensors, switches, and relays carefully. Do not drop them or strike them against other objects.




Wiring Harness

Wiring color codes

- Two-color wires are indicated by a two-color code symbol.
- The first letter indicates the base color of the wire and the second the color of the stripe.

CODE	COLOR	CODE	COLOR
B	Black	O	Orange
BR	Brown	P	Pink
G	Green	R	Red
GY	Gray	V	Violet
L	Blue	W	White
LB	Light Blue	Y	Yellow
LG	Light Green		



End Of Site

NEW STANDARDS

NEW STANDARDS

NEW STANDARDS TABLE

AME202800020M01

- Following is a comparison of the previous standard and the new standard.

New Standard		Previous Standard		Remark
Abbreviation	Name	Abbreviation	Name	
AP	Accelerator Pedal	—	Accelerator Pedal	
ACL	Air Cleaner	—	Air Cleaner	
A/C	Air Conditioning	—	Air Conditioning	
BARO	Barometric Pressure	—	Atmospheric Pressure	
B+	Battery Positive Voltage	V _B	Battery Voltage	
—	Brake Switch	—	Stoplight Switch	
—	Calibration Resistor	—	Corrected Resistance	#6
CMP sensor	Camshaft Position Sensor	—	Crank Angle Sensor	
CAC	Charge Air Cooler	—	Intercooler	
CLS	Closed Loop System	—	Feedback System	
CTP	Closed Throttle Position	—	Fully Closed	
CPP	Clutch Pedal Position	—	Idle Switch	
CIS	Continuous Fuel Injection System	—	Clutch Position	
CS sensor	Control Sleeve Sensor	CSP sensor	Control Sleeve Position Sensor	#6
CKP sensor	Crankshaft Position Sensor	—	Crank Angle Sensor 2	
DLC	Data Link Connector	—	Diagnosis Connector	
DTM	Diagnostic Test Mode	—	Test Mode	#1
DTC	Diagnostic Trouble Code(s)	—	Service Code(s)	
DI	Distributor Ignition	—	Spark Ignition	
DLI	Distributorless Ignition	—	Direct Ignition	
EI	Electronic Ignition	—	Electronic Spark Ignition	#2
ECT	Engine Coolant Temperature	—	Water Thermo	
EM	Engine Modification	—	Engine Modification	
—	Engine Speed Input Signal	—	Engine RPM Signal	
EVAP	Evaporative Emission	—	Evaporative Emission	
EGR	Exhaust Gas Recirculation	—	Exhaust Gas Recirculation	
FC	Fan Control	—	Fan Control	
FF	Flexible Fuel	—	Flexible Fuel	
4GR	Fourth Gear	—	Overdrive	
—	Fuel Pump Relay	—	Circuit Opening Relay	#3
FSO solenoid	Fuel Shut Off Solenoid	FCV	Fuel Cut Valve	#6
GEN	Generator	—	Alternator	
GND	Ground	—	Ground/Earth	
HO2S	Heated Oxygen Sensor	—	Oxygen Sensor	With heater
IAC	Idle Air Control	—	Idle Speed Control	
—	IDM Relay	—	Spill Valve Relay	#6
—	Incorrect Gear Ratio	—	—	
—	Injection Pump	FIP	Fuel Injection Pump	#6
—	Input/Turbine Speed Sensor	—	Pulse Generator	
IAT	Intake Air Temperature	—	Intake Air Thermo	
KS	Knock Sensor	—	Knock Sensor	
MIL	Malfunction Indicator Lamp	—	Malfunction Indicator Light	
MAP	Manifold Absolute Pressure	—	Intake Air Pressure	
MAF sensor	Mass Air Flow Sensor	—	Airflow Sensor	
MFL	Multiport Fuel Injection	—	Multiport Fuel Injection	
OBD	On-Board Diagnostic	—	Diagnosis/Self Diagnosis	
OL	Open Loop	—	Open Loop	

NEW STANDARDS

New Standard		Previous Standard		Remark
Abbreviation	Name	Abbreviation	Name	
—	Output Speed Sensor	—	Vehicle Speed Sensor 1	
OC	Oxidation Catalytic Converter	—	Catalytic Converter	
O2S	Oxygen Sensor	—	Oxygen Sensor	
PNP	Park/Neutral Position	—	Park/Neutral Range	
—	PCM Control Relay	—	Main Relay	#6
PSP	Power Steering Pressure	—	Power Steering Pressure	
PCM	Powertrain Control Module	ECU	Engine Control Unit	#4
—	Pressure Control Solenoid	—	Line Pressure Solenoid Valve	
PAIR	Pulsed Secondary Air Injection	—	Secondary Air Injection System	Pulsed injection
—	Pump Speed Sensor	—	NE Sensor	#6
AIR	Secondary Air Injection	—	Secondary Air Injection System	Injection with air pump
SAPV	Secondary Air Pulse Valve	—	Reed Valve	
SFI	Sequential Multipoint Fuel Injection	—	Sequential Fuel Injection	
—	Shift Solenoid A	—	1-2 Shift Solenoid Valve	
		—	Shift A Solenoid Valve	
—	Shift Solenoid B	—	2-3 Shift Solenoid Valve	
		—	Shift B Solenoid Valve	
—	Shift Solenoid C	—	3-4 Shift Solenoid Valve	
3GR	Third Gear	—	3rd Gear	
TWC	Three Way Catalytic Converter	—	Catalytic Converter	
TB	Throttle Body	—	Throttle Body	
TP sensor	Throttle Position Sensor	—	Throttle Sensor	
TCV	Timer Control Valve	TCV	Timing Control Valve	#6
TCC	Torque Converter Clutch	—	Lockup Position	
TCM	Transmission (Transaxle) Control Module	—	ECAT Control Unit	
—	Transmission (Transaxle) Fluid Temperature Sensor	—	ATF Thermosensor	
TR	Transmission (Transaxle) Range	—	Inhibitor Position	
TC	Turbocharger	—	Turbocharger	
VSS	Vehicle Speed Sensor	—	Vehicle Speed Sensor	
VR	Voltage Regulator	—	IC Regulator	
VAF sensor	Volume Air Flow Sensor	—	Air flow Sensor	
WUTWC	Warm Up Three Way Catalytic Converter	—	Catalytic Converter	#5
WOT	Wide Open Throttle	—	Fully Open	

#1 : Diagnostic trouble codes depend on the diagnostic test mode

#2 : Controlled by the PCM

#3 : In some models, there is a fuel pump relay that controls pump speed. That relay is now called the fuel pump relay (speed).

#4 : Device that controls engine and powertrain

#5 : Directly connected to exhaust manifold

#6 : Part name of diesel engine

End Of Site

ABBREVIATIONS

ABBREVIATIONS

ABBREVIATIONS TABLE

AME203000011M01

SST	Special service tool
-----	----------------------

End Of Sie

OVERHAUL

J

MANUAL TRANSAXLE	J-2
PRECAUTION.....	J-2
CLUTCH HOUSING AND TRANSAXLE CASE	
COMPONENTS DISASSEMBLY.....	J-3
PRIMARY SHAFT COMPONENTS	
PREINSPECTION.....	J-8
PRIMARY SHAFT COMPONENTS	
DISASSEMBLY.....	J-9
PRIMARY SHAFT COMPONENTS	
INSPECTION	J-11
PRIMARY SHAFT COMPONENTS	
ASSEMBLY.....	J-13
SECONDARY SHAFT COMPONENTS	
PREINSPECTION.....	J-18
SECONDARY SHAFT COMPONENTS	
DISASSEMBLY.....	J-19
SECONDARY SHAFT COMPONENTS	
INSPECTION	J-20
SECONDARY SHAFT COMPONENTS	
ASSEMBLY.....	J-24
REVERSE IDLER SHAFT COMPONENTS	
DISASSEMBLY/ASSEMBLY	J-30
REVERSE IDLER SHAFT COMPONENTS	
INSPECTION	J-31
DIFFERENTIAL PREINSPECTION	J-32
DIFFERENTIAL DISASSEMBLY	J-32
DIFFERENTIAL ASSEMBLY	J-33
PRIMARY SHAFT END PLAY ADJUSTMENT..	J-35
SECONDARY SHAFT END PLAY	
ADJUSTMENT	J-36
REVERSE IDLER GEAR END PLAY	
ADJUSTMENT	J-37
DIFFERENTIAL SIDE BEARING PRELOAD	
ADJUSTMENT	J-38
CLUTCH HOUSING AND TRANSAXLE CASE	
COMPONENTS ASSEMBLY	J-40

MANUAL TRANSAXLE

MANUAL TRANSAXLE

PRECAUTION

AME511201029M09

1. Clean the transaxle exterior thoroughly using a steam cleaner or cleaning solvents before disassembly.

Warning

- Using compressed air can cause dirt and other particles to fly out, causing injury to the eyes. Wear protective eye wear whenever using compressed air.

Caution

- Cleaning sealed bearings using cleaning fluids or a steam cleaner can wash the grease out of the bearing.

2. Clean the removed parts using cleaning solvent, and dry them using compressed air.
3. Clean out all holes and passages using compressed air, and check that there are no obstructions.
4. Use a plastic hammer when disassembling the transaxle case and other light alloy metal parts.
5. Make sure each part is cleaned before assembling.
6. Coat all movable parts with the specified oil.
7. Replace parts whenever required.
8. Remove old sealant from contact surfaces before applying new sealant.
9. Assemble the parts within **10 minutes** after applying sealant. Allow all sealant to cure at least **30 minutes** after assembly before filling the transaxle with transaxle oil.

Warning

- Although the stand has a self-locking brake system, there is a possibility that the brake may not hold when the transaxle is held in a lopsided position on the stand. This would cause the transaxle to turn suddenly, causing serious injury. Never keep the transaxle tilted to one side. Always hold the rotating handle firmly when turning the transaxle.


End Of Site

MANUAL TRANSAXLE

CLUTCH HOUSING AND TRANSAXLE CASE COMPONENTS DISASSEMBLY

AME511217010M01

Disassembly Components




AME5112M004

1	Drain plug
2	Filler cap
3	Neutral switch
4	Reverse switch
5	Air-bleed plug
6	Bore plug
7	Welt plug
8	Baffle plate
9	Oil pass
10	Transaxle case

11	Pivot pin
12	Magnet
13	Differential oil seal
14	Knock pin
15	Dowel pin
16	Secondary shaft bearing retainer
17	Secondary shaft front bearing
18	Oil channel
19	Primary shaft oil seal
20	Clutch housing

MANUAL TRANSAXLE



B6U0515M001


1	Stopper bolt
2	Shift check bolt
3	Shift control component
4	O ring
5	Rod bushing
6	Reverse lever component
7	Reverse fork rod
8	Cap
9	Reverse shift fork
10	Retaining pin
11	C ring
12	5th/Reverse fork rod
13	5th shift fork
14	5th/reverse bracket
15	Check plug (5th/reverse)

16	Check spring (5th/reverse)
17	Shift check sleeve (5th/reverse)
18	Check ball
19	Inter lock pin
20	3rd/4th fork rod
21	3rd/4th shift fork
22	3rd/4th bracket
23	Shift check sleeve (1st/2nd)
24	1st/2nd fork rod
25	1st/2nd bracket
26	1st/2nd shift fork
27	Clutch housing
28	Transaxle case
29	Check plug (1st/2nd, 3rd/4th)
30	Check spring (1st/2nd)
31	Check spring (3rd/4th)

MANUAL TRANSAXLE


Disassembly Procedure

1. Remove the drain plug and the filler cap.
2. Remove the neutral switch and reverse switch.
3. Remove the shift check bolt and stopper bolt.
4. Remove the shift control component.




AME5112M098

5. Remove the check plugs, check springs, check balls, and shift check sleeve as shown in the figure.




AME5112M142

6. Remove the transaxle case installation bolt.
7. Remove the bore plug using screwdriver.
8. Stretch the snap ring of the secondary shaft rear bearing at the bore plug hole, and remove the transaxle case.
9. Remove the baffle plate and the oil pass.
10. Remove the snap ring, secondary shaft adjust shim, primary shaft rear bearing adjust shim from the transaxle case.



AME5112M007


11. Remove the differential side bearing outer race (transaxle case side) using the SST, and remove the adjust shim.



AME5112M101

MANUAL TRANSAXLE

12. Remove the welt plug using a fit stick.
13. Remove the differential oil seal (transaxle case side) using a screwdriver.
14. Remove the magnet from clutch housing.
15. Shift to 5th gear.




AME5112M008

16. Remove the reverse lever component bracket bolt.

Caution


- When reusing bolts, completely remove any remaining sealant from the bolts and threaded holes.

17. Lift the reverse lever component, and remove it.
18. Remove the reverse fork rod.
19. Remove the reverse shift fork.




AME5112M009

20. Shift 3rd/4th fork rod to the 3rd gear, and remove the retaining pin of 5th shift fork using a pin punch.




AME5112M010

21. Remove the C ring of the 5th/reverse bracket.
22. Remove the 5th/reverse fork rod, and remove the 5th shift fork and 5th/reverse bracket.
23. Remove the check balls and the interlock pin from the clutch housing.



AME5112M011


24. Remove the retaining pin of 3rd/4th fork rod bracket using a pin punch.
25. Remove the two C rings of the 3rd/4th shift fork.
26. Remove the 3rd/4th fork rod, and remove the 3rd/4th shift fork and 3rd/4th bracket.
27. Remove the shift check sleeve from the clutch housing.



AME5112M012

MANUAL TRANSAXLE

28. Remove the retaining pin of 1st/2nd shift fork using a pin punch.
29. Remove the 1st/2nd fork rod and 1st/2nd bracket at a time.
30. Remove the 1st/2nd shift fork.
31. Remove the retaining pin of the 1st/2nd bracket using a pin punch, and remove the 1st/2nd bracket from the 1st/2nd fork rod.




AME5112M013

32. Remove each gear component.
 - (1) Tap the primary shaft using a plastic hammer.

Caution

- The oil channel in the clutch housing can be damaged when removing the secondary shaft component. Remove the secondary shaft component to right above.



AME5112M014


- (2) Remove the primary shaft component, secondary shaft component, and reverse idler gear component at the same time.
 - (3) Remove the differential.
33. Remove the secondary shaft bearing retainer.

Warning

- Using a heat gun can will cause the clutch housing to heat up greatly. To prevent burns wear gloves whenever using a heat gun.

Caution

- The clutch housing will be damaged if heated above 120 °C. Heat the clutch housing below 120 °C.



AME5112M015


Note

- If the secondary shaft front bearing can't be removed easily, heat the clutch housing to about 100 °C using a heat gun and remove it.

34. Remove the secondary shaft front bearing using a screwdriver.
35. Remove the oil channel of the secondary shaft.
36. Remove the differential oil seal (clutch housing side) using a screwdriver.

Warning

- Using a heat gun will cause the clutch housing to heat up greatly. To prevent burns wear gloves whenever using a heat gun.



AME5112M074

Caution


- The clutch housing will be damaged if heated above 120 °C. Heat the clutch housing below 120 °C.

Note

- If the differential side bearing outer race can't be removed easily, heat the clutch housing to about 100 °C using a heat gun and remove it.


MANUAL TRANSAXLE

37. Remove the differential side bearing outer race using the **SST**.



AME5112M102

38. Remove the primary shaft oil seal using a screwdriver.




AME5112M016

End Of Step

PRIMARY SHAFT COMPONENTS PREINSPECTION

AME511217201M01



AME5112M093

3rd Gear Thrust Clearance

1. Measure the clearance between the 3rd gear and 2nd gear.
 - If not as specified, assemble the primary shaft component again.

Clearance

0.18—0.31 mm {0.0071—0.0122 in}

5th Gear Thrust Clearance

1. Measure the clearance between 4th thrust washer and the 5th gear.
 - If not as specified, assemble the primary shaft component again.

Clearance

0.06—0.16 mm {0.0024—0.0063 in}

4th Gear End Play

1. Remove the primary shaft rear bearing.
2. Set up the primary shaft component, and fix it.
3. Slide the 4th gear up and down, and measure the length of the movement.
 - If not as specified, assemble the primary shaft component again.

Length of the movement


0.20—0.30 mm {0.0078—0.0118 in}

MANUAL TRANSAXLE

PRIMARY SHAFT COMPONENTS DISASSEMBLY

AME511217201M02

1. Disassemble in the order shown in the figure.



AME5112M095


1	Primary shaft rear bearing adjust shim
2	Oil channel
3	Primary shaft rear bearing (See J-10 Primary Shaft Rear Bearing Disassembly Note)
4	Snap ring
5	Primary shaft bearing spacer (See J-10 Primary Shaft Bearing Spacer and 5th Gear Stopper Disassembly Note)
6	5th gear stopper
7	5th clutch hub set (See J-10 5th Clutch Hub Set, 5th Synchronizer Ring and 5th Gear Disassembly Note)
8	5th synchronizer ring
9	5th gear
10	5th needle bearing
11	5th bushing (See J-10 5th Bushing, Thrust Washer, 4th Gear, 4th Needle Bearing, 4th Bushing, 4th Synchronizer Ring, 3rd/4th Clutch Hub Set, 3rd Synchronizer Ring and 3rd Gear Disassembly Note)
12	Thrust washer
13	4th gear

14	4th needle bearing
15	4th bushing
16	4th synchronizer ring
17	3rd/4th clutch hub set
18	3rd synchronizer ring
19	3rd gear
20	3rd needle bearing
21	Primary shaft
22	Primary shaft front bearing (See J-11 Primary Shaft Front Bearing Disassembly Note)
23	Synchronizer key spring (5th)
24	5th synchronizer key
25	5th clutch hub and sleeve
26	3rd/4th synchronizer key
27	3rd/4th clutch hub and sleeve
28	Synchronizer key spring (3rd/4th)

MANUAL TRANSAXLE

Primary Shaft Rear Bearing Disassembly Note


1. Remove the bearing using the SSTs.



AME5112M103

Primary Shaft Bearing Spacer and 5th Gear Stopper Disassembly Note


1. Remove the primary shaft bearing spacer and 5th gear stopper at the same time using the SSTs.



AME5112M106

5th Clutch Hub Set, 5th Synchronizer Ring and 5th Gear Disassembly Note


1. Remove the 5th clutch hub set, 5th synchronizer ring and 5th gear at the same time using the SSTs.



AME5112M108

5th Bushing, Thrust Washer, 4th Gear, 4th Needle Bearing, 4th Bushing, 4th Synchronizer Ring, 3rd/4th Clutch Hub Set, 3rd Synchronizer Ring and 3rd Gear Disassembly Note

1. Remove the 5th bushing, thrust washer, 4th gear, 4th needle bearing, 4th bushing, 4th synchronizer ring, 3rd/4th clutch hub set, 3rd synchronizer ring and 3rd gear at the same time using the SSTs.




AME5112M109

MANUAL TRANSAXLE

Primary Shaft Front Bearing Disassembly Note

1. Remove the primary shaft front bearing using the SST.



AME5112M107


End Of Step

PRIMARY SHAFT COMPONENTS INSPECTION

AME511217201M03

Primary Shaft and Gear Inspection


1. Inspect the shaft for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the shaft.
2. Inspect the gears for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the gear.
3. Inspect the oil passage for clogging.
 - If there is malfunction, replace the shaft.




AME5112M044

Synchronizer Ring and Clutch Hub Component Inspection

1. Inspect the clutch hub sleeve, clutch hub, and synchronizer key contact surface for damage and abnormal wear.
 - If there is malfunction, replace the part where necessary.
2. Verify that the clutch hub sleeve and clutch hub for move smoothly.
 - If there is malfunction, replace parts as necessary.
3. Inspect the synchronizer ring teeth and grooves for damage, abnormal wear, and cracks.
 - If there is malfunction, replace the synchronizer ring.
4. Inspect the tapered surface for abnormal wear and cracks.
 - If there is malfunction, replace parts as necessary.



AME5112M045



AME5112M046

MANUAL TRANSAXLE

5. Measure the clearance between the synchronizer ring and the flank surface of the gear.

- If not as specified, replace the synchronizer ring.

Note

- Set the synchronizer ring squarely in the gear; then measure around the circumference.

Standard clearance


3rd: 0.90—1.45 mm {0.035—0.057 in}

4th: 0.90—1.45 mm {0.035—0.057 in}

5th: 0.95—1.40 mm {0.037—0.055 in}

Minimum clearance


0.70 mm {0.028 in}



AME5112M070

Bearing Inspection

1. Inspect the ball and the ball contact surface for damage and abnormal wear.
 - If there is malfunction, replace the bearing.
2. Verify that the bearing rotates smoothly.
 - If there is malfunction, replace the bearing.



AME5112M072


End Of Site

MANUAL TRANSAXLE

PRIMARY SHAFT COMPONENTS ASSEMBLY

AME511217201M04

1. Assemble in the order shown in the figure.



AME5112M135

1	Primary shaft
2	3rd needle bearing
3	3rd gear
4	3rd synchronizer ring
5	3rd/4th synchronizer key spring (See J-14 3rd/4th Synchronizer Key Spring, 3rd/4th Synchronizer Key and 3rd/4th Clutch Hub and Sleeve Assembly Note)
6	3rd/4th synchronizer key
7	3rd/4th clutch hub and sleeve
8	3rd/4th clutch hub set (See J-14 3rd/4th Clutch Hub Set Assembly Note)
9	4th synchronizer ring
10	4th bushing (See J-15 4th Bushing Assembly Note)
11	4th needle bearing
12	4th gear
13	Primary shaft thrust washer (See J-15 Primary Shaft Thrust Washer Assembly Note)
14	5th bushing (See J-16 5th Bushing Assembly Note)
15	5th needle bearing


16	5th gear
17	5th synchronizer ring
18	5th synchronizer key spring (See J-16 5th Synchronizer Key Spring, 5th Synchronizer Key and 5th Clutch Hub and Sleeve Assembly Note)
19	5th synchronizer key
20	5th clutch hub and sleeve
21	5th clutch hub set (See J-17 5th Clutch Hub Set Assembly Note)
22	5th gear stopper
23	Primary shaft bearing spacer (See J-17 Primary Shaft Bearing Spacer Assembly Note)
24	Snap ring (See J-17 Snap Ring Assembly Note)
25	Primary shaft rear bearing (See J-18 Primary Shaft Rear Bearing Assembly Note)
26	Primary shaft front bearing (See J-18 Primary Shaft Front Bearing Assembly Note)
27	Oil channel
28	Primary shaft rear bearing adjust shim

MANUAL TRANSAXLE


3rd/4th Synchronizer Key Spring, 3rd/4th Synchronizer Key and 3rd/4th Clutch Hub and Sleeve Assembly

Note


1. Install the 3rd/4th synchronizer key spring, 3rd/4th synchronizer key and 3rd/4th clutch hub to the 3rd/4th clutch sleeve.
 - (1) Install a new 3rd/4th clutch hub in the direction as shown in the figure.



- (2) Install a new 3rd/4th clutch sleeve in the direction as shown in the figure.



- (3) Install center projection parts of 3rd/4th synchronizer key springs to different synchronizer keys on each side.




3rd/4th Clutch Hub Set Assembly Note

Note

- Align the synchronizer ring grooves with the synchronizer key during assembly.


1. Install the 3rd/4th clutch hub set using the **SSTs**.



MANUAL TRANSAXLE

4th Bushing Assembly Note


1. Install the 4th bushing using the SSTs.



AME5112M114

Primary Shaft Thrust Washer Assembly Note

1. Install the primary shaft thrust washer using the SSTs.



AME5112M115


2. Measure length C1 as shown in the figure.
 - If it is not within the specification, adjust it by selecting a proper thrust washer from below.
 - Select only one thrust washer.

Specification C1

154.7—154.8 mm {6.091—6.094 in}

Primary shaft thrust washer size

Thickness (mm {in})	
3.84 {0.151}	4.02 {0.158}
3.90 {0.154}	4.08 {0.161}
3.96 {0.156}	4.14 {0.163}




AME5112M050

MANUAL TRANSAXLE

5th Bushing Assembly Note

1. Install a new 5th bushing using the SSTs.




AME5112M116

5th Synchronizer Key Spring, 5th Synchronizer Key and 5th Clutch Hub and Sleeve Assembly Note


1. Assemble the 5th synchronizer key springs, 5th synchronizer key and 5th clutch hub to the 5th clutch sleeve.

- (1) Install a new 5th clutch hub in the direction as shown in the figure.




AME5112M051

- (2) Install a new 5th clutch sleeve in the direction as shown in the figure.



AME5112M052

- (3) Install center projection parts of 5th synchronizer key springs to different synchronizer keys on each side.



AME5112M049


MANUAL TRANSAXLE

5th Clutch Hub Set Assembly Note

Note

- Align the synchronizer ring grooves with the synchronizer key during assembly.


- Install the 5th clutch hub set using the **SSTs**.



AME5112M117

Primary Shaft Bearing Spacer Assembly Note

- Install the primary shaft bearing spacer using the **SSTs**.



AME5112M118

Snap Ring Assembly Note


- Install a new snap ring to the primary shaft.
- Measure the clearance between the snap ring and the primary shaft bearing spacer.
 - If it is not within the specification, adjust it by selecting a proper snap ring from below.

Clearance

0.0—0.1 mm {0.0000—0.0039 in}

Snap ring size

Thickness (mm {in})	
1.71 {0.067}	2.01 {0.079}
1.76 {0.069}	2.06 {0.081}
1.81 {0.071}	2.11 {0.083}
1.86 {0.073}	2.16 {0.085}
1.91 {0.075}	2.21 {0.087}
1.96 {0.077}	2.26 {0.089}




AME5112M053

MANUAL TRANSAXLE

Primary Shaft Rear Bearing Assembly Note


1. Place the primary shaft rear bearing with the brown side facing toward the 5th gear.
2. Install the primary shaft rear bearing using the SSTs.



AME5112M119

Primary Shaft Front Bearing Assembly Note

1. Install the primary shaft front bearing using the SSTs.
2. Inspect the 3rd gear and 5th gear thrust clearance and 4th gear end play. (See [J-8 PRIMARY SHAFT COMPONENTS PREINSPECTION](#).)




AME5112M120

End Of Section

SECONDARY SHAFT COMPONENTS PREINSPECTION

AME511217301M01



AME5112M094

1st Gear End Play

1. Set up the secondary shaft component, and fix it.
2. Slide the 1st gear up and down, and measure the length of the movement.
 - If not as specified, assemble the secondary shaft component again.

Length of the movement

0.20—0.30 mm {0.0078—0.0118 in}

2nd Gear End Play

1. Set up the secondary shaft component, and fix it.
2. Slide the 2nd gear up and down, and measure the length of the movement.
 - If not as specified, assemble the secondary shaft component again.

Length of the movement

0.06—0.16 mm {0.0024—0.0063 in}


End Of Section

MANUAL TRANSAXLE

SECONDARY SHAFT COMPONENTS DISASSEMBLY

AME511217301M02

1. Disassemble in the order shown in the figure.



AME5112M096


1	Secondary shaft rear bearing adjust shim
2	Snap ring
3	Snap ring
4	C ring holder
5	Secondary shaft C ring
6	Secondary shaft rear bearing (See J-20 Secondary Shaft Rear Bearing Disassembly Note)
7	Snap ring
8	5th gear (See J-20 4th Gear and 5th Gear Disassembly Note)
9	4th gear
10	4th gear adjustment shim
11	3rd/4th secondary shaft spacer
12	3rd gear (See J-20 3rd Gear, 2nd Gear, 2nd Needle Bearing, 2nd Bushing, 2nd Inner Synchronizer Component, 1st/2nd Clutch Hub Set, 1st Inner Synchronizer Component, 1st Needle Bearing, 1st Bushing, 1st Gear and Reverse Main Gear Disassembly Note)

13	2nd gear
14	2nd needle bearing
15	2nd bushing
16	2nd inner synchronizer component
17	1st/2nd clutch hub set
18	1st inner synchronizer component
19	1st needle bearing
20	1st bushing
21	1st gear
22	Reverse main gear
23	Secondary shaft
24	Synchronizer key spring
25	1st/2nd synchronizer key
26	1st/2nd clutch hub and sleeve

MANUAL TRANSAXLE

Secondary Shaft Rear Bearing Disassembly Note


1. Remove the secondary shaft rear bearing using the SSTs.



AME5112M113

4th Gear and 5th Gear Disassembly Note


1. Remove the 4th gear and 5th gear at the same time using the SSTs.



AME5112M111

3rd Gear, 2nd Gear, 2nd Needle Bearing, 2nd Bushing, 2nd Inner Synchronizer Component, 1st/2nd Clutch Hub Set, 1st Inner Synchronizer Component, 1st Needle Bearing, 1st Bushing, 1st Gear and Reverse Main Gear Disassembly Note

1. Remove the 3rd gear, 2nd gear, 2nd needle bearing, 2nd bushing, 2nd inner synchronizer component, 1st/2nd clutch hub set, 1st inner synchronizer component, 1st needle bearing, 1st bushing, 1st gear and reverse main gear at the same time using the SST.



AME5112M112


End Of Step

SECONDARY SHAFT COMPONENTS INSPECTION

AME511217301M03

Secondary Shaft and Gear Inspection

1. Inspect the shaft for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the shaft.
2. Inspect the gears for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the gear.
3. Inspect the oil passage for clogging.
 - If there is malfunction, replace the shaft.




AME5112M058


MANUAL TRANSAXLE

Synchronizer Ring and Clutch Hub Component Inspection

1. Inspect the clutch hub sleeve, clutch hub, and synchronizer key contact surface for damage and abnormal wear.
 - If there is malfunction, replace the part where necessary.
2. Verify that the clutch hub sleeve and clutch hub move smoothly.
 - If there is malfunction, replace parts as necessary.
3. Inspect the synchronizer ring teeth and grooves for damage, abnormal wear, and cracks.
 - If there is malfunction, replace the synchronizer ring.
4. Inspect the tapered surface for abnormal wear and cracks.
 - If there is malfunction, replace parts as necessary.



AME5112M045




AME5112M046

Synchronizer Ring Clearance Inspection

Synchronizer component (1st gear)

1. Measure the clearance of synchronizer component outer, middle and inner synchronizer rings.
 - If clearances A and B exceed the maximum, replace as a set.



AME5112M059


- (1) Measure clearance A in two places or more and on opposite sides using a dial gauge, and calculate the average value.

Clearance A

Standard: 0.60—0.80 mm

{0.0236—0.0315 in}

Maximum: 0.20 mm {0.0079 in} or less



AME5112M129

MANUAL TRANSAXLE


- (2) Measure clearance B in two places or more and on opposite sides using a feeler gauge, and calculate the average value.

Clearance B

Standard: 0.60—1.10 mm

{0.0236—0.0433 in}


Maximum: 0.20 mm {0.0079 in} or less



AME5112M060

Synchronizer component (2nd gear)

1. Inspect clearance of the synchronizer component outer, middle, and inner synchronizer rings.
 - If the clearance A, B and C exceed the maximum, replace as a set.



AME5112M092


- (1) Measure clearance A in two places or more and on opposite sides using a feeler gauge while the synchronizer ring is manually press fit to the taper surface of the clutch gear, and calculate the average value.

Clearance A

Standard: 0.60—1.20 mm

{0.0236—0.0472 in}

Maximum: 0.30 mm {0.0118 in} or less



AME5112M090


- (2) Measure clearance B in two places or more and on opposite sides with a feeler gauge, and calculate the average value.

Clearance B

Standard: 0.60—1.10 mm

{0.0236—0.0433 in}

Maximum: 0.20 mm {0.0079 in} or less



AME5112M060

MANUAL TRANSAXLE


- (3) Measure clearance C in two places or more and on opposite sides with a feeler gauge while the synchronizer ring is manually press fit to the taper surface of the clutch gear, and calculate the average value.

Clearance C

Standard: 0.70—1.10 mm

{0.0276—0.0433 in}


Maximum: 0.30 mm {0.0118 in} or less



AME5112M091

Bearing Inspection

1. Inspect the ball and the ball contact surface for damage and abnormal wear.
 - If there is malfunction, replace the bearing.
2. Verify that the bearing rotates smoothly.
 - If there is malfunction, replace the bearing.




End Of Site

MANUAL TRANSAXLE

SECONDARY SHAFT COMPONENTS ASSEMBLY

AME511217301M04

1. Assemble in the order shown in the figure.



AME5112M136


1	Secondary shaft
2	Reverse main gear (See J-25 Reverse Main Gear Assembly Note)
3	1st bushing (See J-25 1st Bushing Assembly Note)
4	1st needle bearing
5	1st gear
6	1st inner synchronizer component
7	Synchronizer key spring (See J-26 Synchronizer Key Spring, 1st/2nd Synchronizer Key and 1st/2nd Clutch Hub and Sleeve Assembly Note)
8	1st/2nd synchronizer key
9	1st/2nd clutch hub and sleeve
10	1st/2nd clutch hub set (See J-26 1st/2nd Clutch Hub Set Assembly Note)
11	2nd inner synchronizer component
12	2nd bushing (See J-27 2nd Bushing Assembly Note)
13	2nd needle bearing
14	2nd gear

15	3rd gear (See J-27 3rd Gear Assembly Note)
16	3rd/4th secondary shaft spacer
17	4th gear adjustment shim (See J-27 4th Gear Adjustment Shim Assembly Note)
18	4th gear (See J-28 4th Gear Assembly Note)
19	5th gear (See J-28 5th Gear Assembly Note)
20	5th gear Snap ring (See J-28 5th Gear Snap Ring Assembly Note)
21	Secondary shaft rear bearing (See J-28 Secondary Shaft Rear Bearing Assembly Note)
22	Secondary shaft C ring (See J-29 Secondary Shaft C Ring Assembly Note)
23	C ring holder
24	Snap ring
25	Snap ring
26	Secondary shaft rear bearing adjust shim


MANUAL TRANSAXLE

Reverse Main Gear Assembly Note

1. Place a new reverse main gear with the bevel edge facing toward the engine.



2. Install the reverse main gear using the **SST**.




1st Bushing Assembly Note


Caution

- The shaft can be damaged when installing the 1st bushing if the SST touches the secondary shaft. Install the SST to the shaft without touching the shaft.

1. Place the 1st bushing, and assemble the **SST** as shown in the figure.



2. Install the 1st bushing using the **SSTs**.




MANUAL TRANSAXLE

Synchronizer Key Spring, 1st/2nd Synchronizer Key and 1st/2nd Clutch Hub and Sleeve Assembly Note


1. Install the synchronizer key spring, 1st/2nd synchronizer key and 1st/2nd clutch hub to the 1st/2nd clutch sleeve.

- (1) Install a new 1st/2nd clutch hub in the direction as shown in the figure.




AME5112M047

- (2) Install the 1st/2nd clutch sleeve in the direction as shown in the figure.



AME5112M063

- (3) Install center projection parts of synchronizer key springs to different synchronizer keys at each side.




AME5112M049

1st/2nd Clutch Hub Set Assembly Note

Note

- Align the synchronizer ring grooves with the synchronizer key during assembly.

1. Install the 1st/2nd clutch hub set using the **SSTs**.




AME5112M123

MANUAL TRANSAXLE


2nd Bushing Assembly Note

1. Install the 2nd bushing using the **SSTs**.



3rd Gear Assembly Note

1. Place a new 3rd gear in the direction as shown in the figure.
2. Install the 3rd gear using the **SST**.



4th Gear Adjustment Shim Assembly Note


1. Install the 4th gear adjustment shim washer.
2. Measure length C2 as shown in the figure.
 - If it is not within the specification, adjust it by selecting a proper 4th gear adjustment shim from below.
 - Select only one 4th gear adjustment shim.

Specification C2

173.85—173.95 mm {6.844—6.848 in}

4th gear adjustment shim size

Thickness (mm {in})	
0.52 {0.021}	0.84 {0.033}
0.60 {0.024}	0.92 {0.036}
0.68 {0.027}	1.00 {0.039}
0.76 {0.030}	1.08 {0.043}




AME5112M064

MANUAL TRANSAXLE

4th Gear Assembly Note


1. Place a new 4th gear in the direction as shown in the figure.
2. Install the 4th gear using the **SST**.



AME5112M126

5th Gear Assembly Note

1. Place a new 5th gear in the direction as shown in the figure.
2. Install the 5th gear using the **SSTs**.



AME5112M127

5th Gear Snap Ring Assembly Note


1. Install a new 5th gear snap ring to the secondary shaft.
2. Measure the clearance between the 5th gear snap ring and the 5th gear.
 - If it is not within the specification, adjust it by selecting a proper snap ring from below.

Clearance

0.0—0.1 mm {0.0000—0.0039 in}

5th gear snap ring size


Thickness (mm {in})	
1.85 {0.073}	2.05 {0.081}
1.90 {0.075}	2.10 {0.083}
1.95 {0.077}	2.15 {0.085}
2.00 {0.079}	2.20 {0.087}



AME5112M065

Secondary Shaft Rear Bearing Assembly Note

1. Install the secondary shaft rear bearing using the **SSTs**.



AME5112M128

MANUAL TRANSAXLE

Secondary Shaft C Ring Assembly Note


1. Install the secondary shaft C ring to the secondary shaft.
2. Measure the clearance between the secondary shaft C ring and the secondary shaft rear bearing.
 - If it is not within the specification, adjust it by selecting a proper C ring from below.

Clearance

0.00—0.06 mm {0.0000—0.0024 in}

Secondary shaft C ring size

Thickness (mm {in})	
2.535 {0.0998}	2.835 {0.1116}
2.565 {0.1010}	2.865 {0.1128}
2.595 {0.1022}	2.895 {0.1140}
2.625 {0.1033}	2.925 {0.1152}
2.655 {0.1045}	2.955 {0.1163}
2.685 {0.1057}	2.985 {0.1175}
2.715 {0.1069}	3.015 {0.1187}
2.745 {0.1081}	3.045 {0.1199}
2.775 {0.1093}	3.075 {0.1211}
2.805 {0.1104}	—



J

3. Inspect the 1st gear and 2nd gear end play. (See [J-18 SECONDARY SHAFT COMPONENTS PREINSPECTION.](#))


End Of Section

MANUAL TRANSAXLE

REVERSE IDLER SHAFT COMPONENTS DISASSEMBLY/ASSEMBLY

AME511217315M01

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.




AME5112M005

1	Reverse idler adjust shim
2	Reverse idler rear gear and reverse coupling sleeve
3	Insert spring (See J-30 Insert Spring Assembly Note)
4	Reverse idler needle bearing
5	Thrust needle bearing

6	Reverse synchronizer ring
7	Reverse idler front gear
8	Reverse idler needle bearing
9	Thrust needle bearing
10	Reverse idler shaft
11	Spring pin

Insert Spring Assembly Note

1. Install the insert spring in the direction as shown in the figure.



AME5112M071

End Of Site


MANUAL TRANSAXLE

REVERSE IDLER SHAFT COMPONENTS INSPECTION

AME511217315M02

Reverse idler shaft and gears Inspection


1. Inspect the shaft for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the shaft.
2. Inspect the gears for damage, abnormal wear, dents, flaking, or bending.
 - If there is malfunction, replace the gear.



AME5112M068


Synchronizer Ring and Clutch Hub Component Inspection

1. Inspect the clutch hub sleeve, clutch hub, and insert spring contact surface for damage, abnormal wear, or bending.
 - If there is malfunction, replace the part where necessary.
2. Verify that the clutch hub sleeve and clutch hub move smoothly.
 - If there is malfunction, replace parts as necessary.



AME5112M139

3. Inspect the synchronizer ring teeth and grooves for damage, abnormal wear, and cracks.
 - If there is malfunction, replace the synchronizer ring.
4. Inspect the tapered surface for abnormal wear and cracks.
 - If there is malfunction, replace parts as necessary.



AME5112M046

5. Measure the clearance between the synchronizer ring and the flank surface of the gear.
 - If not as specified, replace the synchronizer ring.

Note


- Set the synchronizer ring squarely in the gear; then measure around the circumference.

Standard clearance

0.95—1.40 mm {0.037—0.055 in}

Minimum clearance

0.70 mm {0.028 in}




AME5112M070

MANUAL TRANSAXLE

Bearing Inspection

1. Inspect the ball and the ball contact surface for damage and abnormal wear.
 - If there is malfunction, replace the bearing.
2. Verify that the bearing rotates smoothly.
 - If there is malfunction, replace the bearing.



AME5112M072

End Of Step

DIFFERENTIAL PREINSPECTION


AME511227100M01

Backlash Inspection

1. Measure the backlash of the side gear.
 - If not as specified, replace parts as necessary.

Standard

0.10—0.20 mm {0.0039—0.0079 in}




AME5112M140

End Of Step

DIFFERENTIAL DISASSEMBLY

AME511227100M02

1. Disassemble in the order shown in the figure.



AME5112M006


1	Ring gear
2	Bearing (ring gear-opposite side) (See J-33 Bearing (Ring Gear-Opposite Side) Disassembly Note)
3	Spacer

4	Bearing (ring gear side) (See J-33 Bearing (Ring Gear Side) Disassembly Note)
5	Gear case component

MANUAL TRANSAXLE

Bearing (Ring Gear-Opposite Side) Disassembly Note


1. Remove the bearing using the SST.



AME5112M130

Bearing (Ring Gear Side) Disassembly Note

1. Remove the bearing using the SSTs.




AME5112M134

End Of Step

DIFFERENTIAL ASSEMBLY

AME511227100M03

1. Assemble in the order shown in the figure.



AME5112M141

1	Ring gear (See J-34 Ring Gear Assembly Note)
2	Gear case component
3	Bearing (ring gear side) (See J-34 Bearing (Ring Gear Side) Assembly Note)

4	Spacer (See J-34 Spacer Assembly Note)
5	Bearing (ring gear-opposite side) (See J-34 Bearing (Ring Gear-Opposite Side) Assembly Note)

MANUAL TRANSAXLE


Ring Gear Assembly Note

1. Install the gear case component, and tighten a bolt in the order shown in the figure.

Tightening torque

112.7—127.4 N·m


{11.5—13.0 kgf·m, 83—94 ft·lbf}



AME5112M075

Bearing (Ring Gear Side) Assembly Note


1. Install a new bearing using the SSTs.



AME5112M073

Spacer Assembly Note


1. Install the spacer using the SST.



AME5112M131

Bearing (Ring Gear-Opposite Side) Assembly Note

1. Install a new bearing using the SSTs.



AME5112M132

End Of Ste

MANUAL TRANSAXLE

PRIMARY SHAFT END PLAY ADJUSTMENT

AME511201029M07

Note

- Adjust the primary shaft end play by measuring the clearance between the transaxle case and the primary shaft rear bearing, and selecting a primary shaft bearing adjustment shim.
- Calculate adjustment shim thickness O as defined below to adjust the primary shaft bearing end play to standard value.

Standard value: 0.00—0.06 mm


{0.0000—0.0024 in}

$$\text{Dimension O} = (\text{O1} - \text{O2}) - \text{end play}$$

O: adjustment shim thickness

O1: transaxle case contact face and adjustment shim installation surface dimension

O2: clutch housing contact face and primary shaft rear bearing contact face dimension




AME5112M030

Adjustment shim thickness

(mm {in})

0.40 {0.016}	0.76 {0.030}	1.12 {0.044}	1.48 {0.058}
0.44 {0.017}	0.80 {0.031}	1.16 {0.046}	1.52 {0.060}
0.48 {0.019}	0.84 {0.033}	1.20 {0.047}	1.56 {0.061}
0.52 {0.020}	0.88 {0.035}	1.24 {0.049}	1.60 {0.063}
0.56 {0.022}	0.92 {0.036}	1.28 {0.050}	1.64 {0.065}
0.60 {0.024}	0.96 {0.038}	1.32 {0.052}	1.68 {0.066}
0.64 {0.025}	1.00 {0.039}	1.36 {0.054}	1.72 {0.068}
0.68 {0.027}	1.04 {0.041}	1.40 {0.055}	—
0.72 {0.028}	1.08 {0.043}	1.44 {0.057}	—

- Measure dimension O1 for the clutch housing installation surface of the transaxle case and the adjustment shim installation surface using a depth gauge and straight edge.




AME5112M031

- Measure dimension O2 for the transaxle case installation surface of the clutch housing and the primary shaft rear bearing contact face using a depth gauge and straight edge.

Note

- Select only one adjustment shim.

- Install the selected primary shaft rear bearing adjustment shim in the primary shaft component.



AME5112M032

MANUAL TRANSAXLE

SECONDARY SHAFT END PLAY ADJUSTMENT

AME511201029M08

Note

- Adjust the secondary shaft end play by measuring clearance M between the transaxle case and the secondary shaft rear bearing, and selecting a secondary shaft bearing adjustment shim.
- Calculate adjustment shim thickness P as defined below to adjust the secondary shaft bearing end play to standard value.


Standard value: 0.00—0.06 mm

{0.0000—0.0024 in}

Dimension P = M – end play

P: adjustment shim thickness

M: transaxle case contact face and secondary shaft rear bearing contact



AME5112M033

Adjustment shim thickness

(mm {in})


0.40 {0.016}	0.64 {0.025}	0.84 {0.033}	1.04 {0.041}
0.48 {0.019}	0.68 {0.027}	0.88 {0.035}	1.08 {0.043}
0.52 {0.020}	0.72 {0.028}	0.92 {0.036}	—
0.56 {0.022}	0.76 {0.030}	0.96 {0.038}	—
0.60 {0.024}	0.80 {0.031}	1.00 {0.039}	—

- Install the secondary shaft component to the clutch housing.
- Install the snap ring to the transaxle case.
- Attach the transaxle case to the clutch housing, and temporarily install installation bolts. Temporarily attach the snap ring to the secondary shaft rear bearing.
- Set a dial gauge to the secondary shaft rear bearing through the snap ring installation hole.
- While expanding the snap ring, lift the secondary shaft component through the control component installation hole until it contacts the transaxle case.
- Release the secondary shaft component so that it moves back down and the snap ring resets to the secondary shaft rear bearing. Dimension M is the measured distance that the secondary shaft component moves.

Note

- Select only one adjustment shim.

- Install the selected primary shaft rear bearing adjustment shim in the primary shaft component.



AME5112M034

END OF SIE

MANUAL TRANSAXLE

REVERSE IDLER GEAR END PLAY ADJUSTMENT

AME511201029M06

Caution

- The reverse idler gear will not function properly if the lip of the friction damper comes out of contact with the inner side of the gear. When moving the reverse idler gear component, do not handle the reverse idler gear. Move the component by grasping the ends of the reverse idler shaft.

Note

- Adjust the reverse idler gear end play by measuring the clearance between the transaxle case and a reverse idler gear (rear), and selecting a reverse idler gear adjustment shim.
- Calculate dimension Q for the adjustment shim thickness as defined below to adjust the reverse idler gear end play to standard value.


Standard value: 0.04—0.10 mm
{0.0016—0.0039 in}

Dimension Q = (Q1 - Q2) - end play

Q: adjustment shim thickness

Q1: transaxle case contact face and adjustment shim installation surface dimension

Q2: clutch housing contact face and reverse idler gear (rear) contact face dimension




AME5112M039

Adjustment shim thickness

(mm {in})

1.76 {0.069}	2.00 {0.007}	2.24 {0.088}	2.48 {0.098}
1.80 {0.070}	2.04 {0.080}	2.28 {0.090}	2.52 {0.099}
1.84 {0.072}	2.08 {0.082}	2.32 {0.091}	2.56 {0.101}
1.88 {0.074}	2.12 {0.083}	2.36 {0.093}	2.60 {0.102}
1.92 {0.076}	2.16 {0.085}	2.40 {0.094}	2.64 {0.104}
1.96 {0.077}	2.20 {0.087}	2.44 {0.096}	—

- Measure dimension Q1 between clutch housing installation surface of the transaxle case and adjustment shim installation surface using a depth gauge and straight edge.




AME5112M040

- Measure dimension Q2 between the transaxle case installation surface of the clutch housing and the reverse idler gear (rear) contact face using a depth gauge and straight edge.

Note

- Select only one adjustment shim.

- Install the selected reverse idler gear adjustment shim in the reverse idler gear component.



AME5112M041

END OF SIDE

MANUAL TRANSAXLE

DIFFERENTIAL SIDE BEARING PRELOAD ADJUSTMENT

AME511201029M05

Note

- Adjust the differential side bearing preload by measuring clearance L between the transaxle case and the differential side bearing outer race, and selecting a differential side bearing adjustment shim.
- Calculate dimension L for the adjustment shim thickness as defined below to adjust the differential side bearing preload to standard value.

Standard value: 0.15—0.21 mm


{0.0059—0.0083 in}

$$\text{Dimension } L = (L1 - L2) + \text{preload}$$

L: adjustment shim thickness

L1: transaxle case contact face and adjustment shim installation surface dimension

L2: clutch housing contact face and differential side bearing contact face dimension




AME5112M035

Adjustment shim thickness

(mm {in})

0.48 {0.019}	0.60 {0.024}	0.72 {0.028}	0.84 {0.033}
0.52 {0.020}	0.64 {0.025}	0.76 {0.030}	0.88 {0.035}
0.56 {0.022}	0.68 {0.027}	0.80 {0.031}	0.92 {0.036}

- Measure dimension L1 between the clutch housing installation surface of the transaxle case and the adjustment shim installation surface using a depth gauge and straight edge.
- Install the outer race to the ring gear side of the differential side bearing and, keeping the outer race level, lightly push it in and rotate the final gear 5 times or more.




AME5112M036

- Verify dimension L2 between the differential side bearing outer race and the transaxle case installation surface of the clutch housing using a depth gauge and straight edge.

Note


- Select up to 2 adjustment shims.



AME5112M037

MANUAL TRANSAXLE

4. Install selected adjustment shim, and install the differential side bearing outer race using the **SSTs**.



AME5112M038

End Of Side


J

MANUAL TRANSAXLE

CLUTCH HOUSING AND TRANSAXLE CASE COMPONENTS ASSEMBLY

AME511217010M05

Assembly Components




AME5112M137

1	Clutch housing
2	Primary shaft oil seal
3	Oil channel
4	Secondary shaft front bearing
5	Secondary shaft bearing retainer
6	Dowel pin
7	Knock pin
8	Differential oil seal
9	Magnet
10	Pivot pin

11	Transaxle case
12	Oil pass
13	Baffle plate
14	Welt plug
15	Bore plug
16	Air-bleed plug
17	Reverse switch
18	Neutral switch
19	Filler cap
20	Drain plug

MANUAL TRANSAXLE

J



B6U0515M002


1	Transaxle case
2	Clutch housing
3	1st/2nd shift fork
4	1st/2nd bracket
5	1st/2nd fork rod
6	Shift check sleeve (1st/2nd)
7	3rd/4th bracket
8	3rd/4th shift fork
9	3rd/4th fork rod
10	Inter lock pin
11	Check ball
12	Shift check sleeve (5th/reverse)
13	Check spring (5th/reverse)
14	Check plug (5th/reverse)
15	5th/reverse bracket
16	5th shift fork

17	5th/Reverse fork rod
18	C ring
19	Retaining pin
20	Reverse shift fork
21	Cap
22	Reverse fork rod
23	Reverse lever component
24	Rod bushing
25	O ring
26	Shift control component
27	Shift check bolt
28	Stopper bolt
29	Check spring (3rd/4th)
30	Check spring (1st/2nd)
31	Check plug (1st/2nd, 3rd/4th)

MANUAL TRANSAXLE


Assembly Procedure

1. Install a new primary shaft oil seal in the clutch housing using the **SST**.



AME5112M017

2. Install a new differential oil seal (clutch housing side) using the **SSTs** so that the seal is flush with the housing surface.




AME5112M105

3. Install a new oil channel in the secondary shaft.


Note

- When installing the oil channel, set the rib part of the oil channel to the hollow processing part of the clutch housing.



AME5112M018

4. Install a new secondary shaft front bearing using the **SSTs** as shown in the figure.



AME5112M019


MANUAL TRANSAXLE

5. Install the bearing retainer with the stamp facing up.

Tightening torque


6.27—8.33 N·m

{0.64—0.85 kgf·m, 4.62—6.14 ft·lbf}




AME5112M020

6. Measure the differential preload, and install the differential side bearing outer race using the **SSTs**. (See [J-38 DIFFERENTIAL SIDE BEARING PRELOAD ADJUSTMENT](#).)



AME5112M021




AME5112M038

7. Install the differential to the clutch housing.

Caution


- Installing the primary shaft can damage the oil seal, reducing the performance of the transaxle. When installing the primary shaft to the clutch housing, be careful not to damage it.

- The reverse idler gear will not function properly if the lip of the friction damper comes out of contact with the inner side of the gear. When moving the reverse idler gear component, do not handle the reverse idler gear. Move the component by grasping the ends of the reverse idler shaft.



AME5112M022


8. Install the primary shaft component, secondary shaft component, and reverse idler component to the clutch housing at the same time.



AME5112M014


MANUAL TRANSAXLE

9. Install the 1st /2nd bracket to the 1st/2nd fork rod, and install a new retaining pin.




AME5112M023

10. Install the 1st/2nd fork rod and 1st/2nd shift fork to the clutch housing, and install a new retaining pin.
11. Install the shift check sleeve.
12. Install the interlock pin to the 3rd/4th fork rod.
13. Install the 3rd/4th bracket, 3rd/4th shift fork, and 3rd/4th fork rod to the clutch housing.




AME5112M013

14. Install a new C ring to the 3rd/4th shift fork.
15. Install a new retaining pin to the 3rd/4th bracket.
16. Install two check balls.
17. Install the 5th/reverse bracket, 5th shift fork, and 5th/reverse fork rod.




AME5112M012

18. Install a new C ring to the 5th/reverse fork rod.
19. Install a new retaining pin to the 5th shift fork.
20. Install the reverse shift fork and reverse fork rod.



AME5112M011


21. Install the reverse lever component.
(1) Install the cap to the cam part of the reverse lever component, and the reverse lever component to the reverse shift fork.



AME5112M010

MANUAL TRANSAXLE

- (2) Lift the reverse shift fork, and install the cam part of the reverse lever component to the 5th/reverse bracket.



- (3) Install the reverse lever component installation bolts.

Caution


- When reusing bolts, completely remove any remaining sealant from the bolts and threaded holes.

Tightening torque


11.8—15.6 N·m
{1.20—1.59 kgf·m, 8.7—11.5 ft·lbf}

Note

- When install the check ball, keep the check ball from dropping into the mold groove of the hole.




22. Install the check ball, the shift check sleeve (5th/reverse), the check spring (5th/reverse), and a new check plug (5th/reverse).
23. Install the magnet to the clutch housing.
24. Install a new differential oil seal to the transaxle case using the **SSTs** so that the seal is flush with the case surface.
25. Adjust the primary shaft end play. (See [J-35 PRIMARY SHAFT END PLAY ADJUSTMENT.](#))
26. Install the primary shaft adjustment shim to the primary shaft.
27. Install the baffle plate and oil pass.
28. Install the transaxle case.
 - (1) Adjust the secondary shaft end play. (See [J-36 SECONDARY SHAFT END PLAY ADJUSTMENT.](#))
 - (2) Install the secondary shaft rear bearing adjustment shim to the transaxle case.
 - (3) Install a new snap ring of the secondary shaft rear bearing to the transaxle case.
 - (4) Apply a light coat of silicone sealant to the contact surfaces of the transaxle case and the clutch housing.




Sealant

Three Bond product: TB1215




MANUAL TRANSAXLE

- (5) Place the transaxle case to the clutch housing.



AME5112M026

- (6) Stretch the snap ring at the bore plug hole while lifting the secondary shaft at the control component installation hole.
 (7) Install the snap ring to the groove of the secondary shaft rear bearing.




AME5112M100

- (8) Install the A bolt and a new B bolt to the transaxle case as shown in the figure.


Tightening torque

- A: 50.0—53.9 N·m
 {5.1—5.5 kgf·m, 36.9—39.8 ft·lbf}
 B: 63.0—66.9 N·m
 {6.4—6.8 kgf·m, 46.5—49.3 ft·lbf}



AME5112M027


29. Install a new bore plug using the SSTs.



AME5112M028

MANUAL TRANSAXLE

30. Install a new welt plug using the SSTs.



AME5112M029


31. Install the check balls, check springs, and a new check ball plugs as shown in the figure.

Tightening torque

12.7—17.0 N·m

{1.30—1.73 kgf·m, 9.4—12.5 ft·lbf}

32. Install a new O ring to the control component.



AME5112M099

33. Install the control component.

Tightening torque

6.30—8.30 N·m

{0.64—0.85 kgf·m, 4.65—6.12 ft·lbf}

34. Install a new shift check bolt.

Tightening torque

22.5—25.5 N·m


{2.29—2.60 kgf·m, 16.6—18.8 ft·lbf}

35. Install a new stopper bolt.

Tightening torque

26.5—30.4 N·m

{2.70—3.10 kgf·m, 19.5—22.4 ft·lbf}



AME5112M098

36. Apply a light coat of silicone sealant to the screw of the neutral switch, and install it to the transaxle case.

Sealant

Three Bond product: TB1215

Tightening torque

22.5—33.3 N·m {2.29—3.40 kgf·m, 16.6—24.6 ft·lbf}

37. Apply a light coat of silicone sealant to the screw of the reverse switch, and install it to the transaxle case.

Sealant

Three Bond product: TB1215

Tightening torque

22.5—33.3 N·m {2.29—3.40 kgf·m, 16.6—24.6 ft·lbf}

38. Install a new drain plug.

Tightening torque

30.0—39.0 N·m {3.06—3.98 kgf·m, 22.1—28.8 ft·lbf}

39. Install a new gasket to the filler cap, and Install it to the transaxle case.

Tightening torque

30.0—39.0 N·m {3.06—3.98 kgf·m, 22.1—28.8 ft·lbf}

2005

TECHNICAL DATA

TECHNICAL DATA	TD-2
MANUAL TRANSAXLE.....	TD-2

TECHNICAL DATA

TECHNICAL DATA

MANUAL TRANSAXLE


AME931001029M01

Item			Specification
Transaxle type			A65M-R
Gear clearance	1st gear	End play (mm {in})	0.20—0.30 {0.0078—0.0118}
	2nd gear	End play (mm {in})	0.06—0.16 {0.0024—0.0063}
	3rd gear	Thrust clearance (mm {in})	0.18—0.31 {0.0071—0.0122}
	4th gear	End play (mm {in})	0.20—0.30 {0.0078—0.0118}
	5th gear	Thrust clearance (mm {in})	0.06—0.16 {0.0024—0.0063}
Synchronizer ring	1st gear	Clearance B* ¹ (mm {in})	0.60—1.10 {0.0236—0.0433}
		Clearance C* ¹ (mm {in})	0.60—0.80 {0.0236—0.0315}
	2nd gear	Clearance A* ¹ (mm {in})	0.60—1.20 {0.0236—0.0472}
		Clearance B* ¹ (mm {in})	0.60—1.10 {0.0236—0.0433}
		Clearance C* ¹ (mm {in})	0.70—1.10 {0.0276—0.0433}
	3rd gear	Clearance (mm {in})	0.90—1.45 {0.035—0.057}
	4th gear	Clearance (mm {in})	0.90—1.45 {0.035—0.057}
	5th gear	Clearance (mm {in})	0.95—1.40 {0.037—0.055}
Primary shaft	Reverse idler gear	Clearance (mm {in})	0.95—1.40 {0.037—0.055}
	End play (mm {in})		0.00—0.06 {0.0000—0.0024}
Secondary shaft	Adjustment shim thickness (mm {in})		0.40 {0.016}, 0.44 {0.017}, 0.48 {0.019}, 0.52 {0.020}, 0.56 {0.022}, 0.60 {0.024}, 0.64 {0.025}, 0.68 {0.027}, 0.72 {0.028}, 0.76 {0.030}, 0.80 {0.031}, 0.84 {0.033}, 0.88 {0.035}, 0.92 {0.036}, 0.96 {0.038}, 1.00 {0.039}, 1.04 {0.041}, 1.08 {0.043}, 1.12 {0.044}, 1.16 {0.046}, 1.20 {0.047}, 1.24 {0.049}, 1.28 {0.050}, 1.32 {0.052}, 1.36 {0.054}, 1.40 {0.055}, 1.44 {0.057}, 1.48 {0.058}, 1.52 {0.060}, 1.56 {0.061}, 1.60 {0.063}, 1.64 {0.065}, 1.68 {0.66}, 1.72 {0.68}
	End play (mm {in})		0.00—0.06 {0.0000—0.0024}
Reverse idler gear	Adjustment shim thickness (mm {in})		0.40 {0.016}, 0.48 {0.019}, 0.52 {0.020}, 0.56 {0.022}, 0.60 {0.024}, 0.64 {0.025}, 0.68 {0.027}, 0.72 {0.028}, 0.76 {0.030}, 0.80 {0.031}, 0.84 {0.033}, 0.88 {0.035}, 0.92 {0.036}, 0.96 {0.038}, 1.00 {0.039}, 1.04 {0.041}, 1.08 {0.043}
	End play (mm {in})		0.04—0.10 {0.0016—0.0039}
Primary shaft thrust washer	Adjustment shim thickness (mm {in})		1.76 {0.069}, 1.80 {0.070}, 1.84 {0.072}, 1.88 {0.074}, 1.92 {0.076}, 1.96 {0.077}, 2.00 {0.079}, 2.04 {0.080}, 2.08 {0.082}, 2.12 {0.083}, 2.16 {0.085}, 2.20 {0.087}, 2.24 {0.088}, 2.28 {0.090}, 2.32 {0.091}, 2.36 {0.093}, 2.40 {0.094}, 2.44 {0.096}, 2.48 {0.098}, 2.52 {0.099}, 2.56 {0.101}, 2.60 {0.102}, 2.64 {0.104}
	Thickness (mm {in})		3.84 {0.151}, 3.90 {0.154}, 3.96 {0.156}, 4.02 {0.158}, 4.08 {0.161}, 4.14 {0.163}
Primary shaft snap ring	Adjustment shim thickness (mm {in})		1.71 {0.067}, 1.76 {0.069}, 1.81 {0.071}, 1.86 {0.073}, 1.91 {0.075}, 1.96 {0.077}, 2.01 {0.079}, 2.06 {0.081}, 2.11 {0.083}, 2.16 {0.085}, 2.21 {0.087}, 2.26 {0.089}
	Thickness (mm {in})		0.52 {0.021}, 0.60 {0.024}, 0.68 {0.027}, 0.76 {0.030}, 0.84 {0.033}, 0.92 {0.036}, 1.00 {0.039}, 1.08 {0.043}

TECHNICAL DATA

Item		Specification
5th gear snap ring	Thickness (mm {in})	1.85 {0.073}, 1.90 {0.075}, 1.95 {0.077}, 2.00 {0.079}, 2.05 {0.081}, 2.10 {0.083}, 2.15 {0.085}, 2.20 {0.087}
Secondary shaft C ring	Thickness (mm {in})	2.535 {0.0998}, 2.565 {0.1010}, 2.595 {0.1022}, 2.625 {0.1033}, 2.655 {0.1045}, 2.685 {0.1057}, 2.715 {0.1069}, 2.745 {0.1081}, 2.775 {0.1093}, 2.805 {0.1104}, 2.835 {0.1116}, 2.865 {0.1128}, 2.895 {0.1140}, 2.925 {0.1152}, 2.955 {0.1163}, 2.985 {0.1175}, 3.015 {0.1187}, 3.045 {0.1199}, 3.075 {0.1211}
Differential	Preload (mm {in})	0.15—0.21 {0.0059—0.0083}
	Adjustment shim thickness (mm {in})	0.48 {0.019}, 0.52 {0.020}, 0.56 {0.022}, 0.60 {0.024}, 0.64 {0.025}, 0.68 {0.027}, 0.72 {0.028}, 0.76 {0.030}, 0.80 {0.031}, 0.84 {0.033}, 0.88 {0.035}, 0.92 {0.036}
	Backlash of side gear and pinion gear (mm {in})	0.10—0.20 {0.0039—0.0079}

*1 : Measure the clearance A, B or C as shown in the figure.



AME5112M092

End Of Site

SPECIAL TOOLS

SPECIAL TOOLSST-2
MANUAL TRANSAXLE.....ST-2

















ST

SPECIAL TOOLS

SPECIAL TOOLS

MANUAL TRANSAXLE

AME941001029M01

49 0710 520 Bearing puller 	49 0727 415 Bearing installer 	49 0839 425C Bearing puller set 
498 B019 014 Removing plate 	49 F026 103 Wheel hub puller 	49 F401 331 Body 
49 F401 336B Attachment B 	49 F401 337A Attachment C 	49 G027 002 Bearing remover 
49 G030 797 Handle 	49 G033 102 Handle 	49 G033 105 Attachment 
49 H010 401 Oil seal installer 	49 H027 002 Bearing remover 	49 P005 205 Oil seal installer 
49 S231 506 Body 	49 T017 002 Bearing installer 	49 U027 003 Oil seal installer 
49 W032 2A0 Bearing remover set 	49 G030 796 Body 	—

End Of Site